



# AU-A220

Digital/Analog Stereo Audio Amplifier

**Driver User Guide**



# CONTENTS

|   |          |
|---|----------|
| <b>1. Introduction .....</b>            | <b>1</b> |
| <b>2. Driver Properties .....</b>       | <b>1</b> |
| <b>3. Device Specific Command .....</b> | <b>2</b> |
| 3.1 Set Power .....                     | 2        |
| 3.2 Set System Reboot .....             | 2        |
| 3.3 Set Audio Out Mute .....            | 2        |
| 3.4 Set Audio Out Volume .....          | 2        |

## 1. INTRODUCTION

This driver has been designed to provide one-way control of the CYP Digital/Analog Stereo Audio Amplifier, via RS232.

## 2. DRIVER PROPERTIES

The property of this driver is shown below

|                |               |
|----------------|---------------|
| Driver Version | 1             |
| Debug Mode     | Print and Log |
| Debug Level    | 5 - Debug     |

Figure 1: Driver Properties

- /// **Driver Version** Driver version number
- /// **Debug Mode** Support use only
- /// **Debug Level** Support use only
- /// **Command Delay Milliseconds** a delay of millisecond between commands

### **3. DEVICE SPECIFIC COMMAND**

In addition to the usual Audio Amplifier Controlling functionality supported by Control4, there are a number of device specific commands for the Audio Amplifier Controlling.

#### **3.1 Set Power**

/// Power Status ON or Stand-by

#### **3.2 Set System Reboot**

/// Power Status Reboot

#### **3.3 Set Audio Out Mute**

/// Audio Mute Status Unmute or Mute

#### **3.4 Set Audio Out Volume**

/// Volume 0 to 100

